



PARTNER/PLUS AUGMENTATIVE COMMUNICATION DEVICES

INSTRUCTION SHEET

Congratulations on your purchase of the PARTNER/PLUS Entry-Level Communicator. THE PARTNER/PLUS IS THE FIRST ENTRY-LEVEL AUGMENTATIVE COMMUNICATOR TO OFFER HIGH QUALITY, RELIABLE PERFORMANCE AND MANY IMPORTANT FEATURES FOR A VERY LOW PRICE. PARTNER/PLUS IS MANUFACTURED TO THE HIGHEST COMMERCIAL STANDARDS TO PROVIDE MANY YEARS OF RELIABLE OPERATION. WE FULLY GUARANTEE THE PARTNER/PLUS'S OPERATION. *

DISTINCTIVE FEATURES OF THE PARTNER/PLUS

- DROP RESISTANT, ABLE TO WITHSTAND ROUGH HANDLING.
- WATER RESISTANCE FOR EASY CLEANING.
- THE SHATTERPROOF CASE IS MADE OF A HIGH IMPACT PLASTIC.
- LIGHT WEIGHT AND PORTABLE (LESS THAN 1 LB.)
- THE PARTNER/PLUS GIVES YOU **"REAL-VOICE"** HIGH QUALITY AUDIO REPRODUCTION.
- MESSAGES CAN BE STORED FOR UP TO 100 YEARS WITH NO POWER. CHANGING THE BATTERIES IS A SNAP.
- OBJECTS CAN BE PLACED ON A VELCRO STRIP OR A PICTURE CARD CAN BE PLACED IN A SLOT STANDING UP.
- EACH PARTNER/PLUS CAN CONNECTED TOGETHER TO BUILD A TWO OR MORE MESSAGE COMMUNICATOR.
- LOW PROFILE PANEL ACTUATION FOR PEOPLE WITH LIMITED REACH.
- LOW ACTUATION FORCE, SO PEOPLE WITH LIMITED STRENGTH CAN ACTIVATE THE PARTNER/PLUS.
- IN ADDITION TO THE BUILT-IN MICROPHONE, SPEAKER AND RECORD SWITCH, ONE OUTPUT JACK AND ONE INPUT JACK IS PROVIDED TO TURN ON AN EXTERNAL DEVICE OR BE ACTIVATED THROUGH AN EXTERNAL SWITCH.

*SEE WARRANTY AGREEMENT FOR DETAILS.

GENERAL OPERATION:

All controls are located on the back of the PARTNER/PLUS.

The PARTNER/PLUS augmentative communicator is a self-contained communication device, which permits the user to record and playback 1 message of 30 seconds in length. Graphic overlays (picture cards) can be easily changed by simply sliding them into the designated area on the actuation panel. Objects can be placed on top using the Velcro strip. Laminated or plastic picture cards can be placed in the slot provided on top of the Partner/Plus. Simple to operate, just turn the unit on, adjust the volume and press the panel to activate the message.

BATTERY INSTALLATION

1. Make sure that the PARTNER/PLUS is turned off. Set VOLUME control switch fully to the right, until it clicks off.
2. Turn the PARTNER/PLUS over and lay the front of the unit on a flat stable surface.
3. To gain access to the battery compartment and expose the batteries, remove the screw holding down the plastic battery cover on the bottom of the unit.
4. Remove the old batteries and discard them in accordance with your local recycling laws.
5. Install the new batteries observing the proper polarity and using 3 new AA batteries.
6. Then replace the battery compartment cover by placing the cover over the access hole and tighten up the screw. Insure the battery cover is secure.

RECORD OPERATION:

Note: It is important during any recording operation that the built in microphone located at the back of the PARTNER/PLUS is clear and open.

1. Turn the PARTNER/PLUS ON. Turn the VOLUME control switch clockwise, until it clicks ON.
2. Set the VOLUME control, turning to the left, until it reaches the center of the range.
3. Depress and hold the built-in record switch. The record switch must be engaged for the entire recording process.
4. Press and hold down the message plate and the Recording LED on the back next to the Recording button will turn on.
5. As soon as the Recording LED turns ON begin to say your message into the built-in microphone located at the back of the PARTNER/PLUS next to the volume control wheel. For the best results, you should speak directly into the microphone and be about 6 to 9 inches away from it in a quiet location, any surrounding noise will be in the background of the recording.
6. When you are finished speaking your message, release the message plate and then the Recording button.

EXTERNAL SWITCH OPERATION:

PARTNER/PLUS comes fully equipped for external switch operation. The switch jack on the back of the unit corresponds to the message panel of the PARTNER/PLUS. The switch jack operates as a switch closure to operate a low voltage electronic device such as a Toy or an Environmental Control Unit (ECU), Computer Interface or a delay timer.

PLAYBACK OPERATION:

1. Turn the PARTNER/PLUS ON. Turn the VOLUME control switch to the left, until it clicks ON.
2. Set the VOLUME control, turning to the left, until the desired playback volume is reached.
3. Press the message panel on the face of the PARTNER/PLUS and the message will play.

OVERLAY DESIGN AND LAYOUT:

There are several methods you can use to make overlays for the PARTNER/PLUS.

1. Draw or print corresponding icons or words on a sheet of 4" by 4" paper.
2. Develop your custom overlay using our Overlay Designer program.

Care and Maintenance

The PARTNER/PLUS is designed to automatically power down after a message is played. However, the power down mode is still an active mode and drains some power from the battery, affecting battery life. Therefore, if the PARTNER/PLUS is not going to be used for a long period (2 to 3 hours) it is recommended that the unit be turned off.

If the PARTNER/PLUS fails to operate, or operates incorrectly, follow these steps

1. Check if the batteries are installed correctly.
2. Check if the PARTNERPLUS is ON and a Message has been recorded.
3. Turn the PARTNER/PLUS OFF for 15 Seconds, then back ON and retry playback.
4. Replace the Batteries.
5. For further assistance, feel free to contact our technical support team at 1-888-353-2634

Limited Warranty

How do you register your Partner/Plus to get warranty coverage?

Do all the following within 30 days after the date of purchase: completely fill out the Warranty Registration Card included; then detach it and mail it in, along with a copy of your dated sales receipt, to: Advanced Multimedia Devices, Inc., 95 Sherwood Ave., Farmingdale, NY 11735. If you do not include your sales receipt, the warranty will be effective as of the original factory shipping date, as determined by the records of Advanced Multimedia Devices, Inc. (the "Company"). You can also register online.

What does this warranty cover?

The Company warrants that during the warranty period, the Partner/Plus will be free from defects in material and workmanship, and will comply with the Company's published specifications. This warranty only covers product that is owned, registered, and submitted for warranty service by the original retail purchaser ("You", the customer). This warranty is immediately void if any installations, repairs, modifications, or alterations are performed on the Partner/Plus by anyone other than the Company or its Authorized Service Representative. The term "alterations" includes, but is not limited to, the addition or attachment of any non-Company equipment to the Partner/Plus.

What does this warranty NOT cover?

- Product acquired from any source other than the Company or one of its Representative;
- Product that was not properly registered for warranty coverage;
- Product that has been installed, repaired, modified or altered by anyone other than the Company or its Authorized Service Representative;
- Product that the serial number or the Company label, trademark or other markings have been removed, altered, concealed or obliterated in whole or in part;
- Expendable components, including but not limited to batteries and the changing of batteries;
- Any product failure or defects caused by misuse, physical abuse, failure to keep the product clean, abnormal or unusual handling, or neglect (all of which shall be determined by the Company's sole judgment);
- Incidental damages (which include, but not limited to, loss of use, replacement costs during the time the product may not work and the costs of shipping the product to and from the Company or its Authorized Service Representative for warranty service) and;
- Consequential damages (the cost of repairing or replacing other property which was damaged when you used this product, or when this product did not work properly).

What is the period of warranty coverage?

This warranty remains in force for 2 years from the date of purchase by the original retail purchaser. The date of purchase is indicated on your sales receipt.

What will we do to correct problems?

The Company, at its option, will refund your purchase price, repair or replace any parts necessary to correct defects in the materials or workmanship, or replace the product with the same model or a substantially similar model.

How do you get warranty service?

If the product requires and qualifies for warranty service, call AMDi @ 1-888-353-AMDi for RMA number, then ship the product prepaid to: AMDi., Service Department, 95 Sherwood Ave., Farmingdale, N.Y. 11735. Be sure to include a letter with your Name, Address, Telephone number and an explanation of the problem.

This is an exclusive warranty.

This warranty is complete and exclusive. In no event shall the Company be liable for special, incidental, or consequential damages arising out of the purchase or use of this product, whether in contract, tort, or negligence. There are no warranties, which extend beyond the description of the face hereof. THE WARRANTIES REFERRED TO HEREIN ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. The Company's maximum liability to you, or to anyone claiming through or on the behalf of you, shall not exceed the amount you paid for the product. No liability shall arise from the Company rendering any advice or providing any information to you. Your continued use of possession of this product after the expiration of the warranty period should be conclusive evidence that the warranty is fulfilled to your full satisfaction.

**95 Sherwood Avenue
Farmingdale, NY 11735**

**Phone: (631) 531-8888
Fax: (631) 531-8811**

**1-888-353-2634
<http://www.admi.net>**